Roc[™] LC Guard Column Holder

for 10 mm Roc[™] Guard Columns

cat.# 25812

The Roc™ LC guard column holder can be used with all HPLC columns with standard 10-32 thread ports.*

Install a Guard Column into the Roc™ Holder

- Open the Roc[™] holder by unscrewing the two halves of the holder
- 2. Insert an appropriate guard column and then reassemble.
- 3. Use two 7 /16" wrenches to tighten the holder approximately 1 /4-turn past finger-tight. Do not overtighten.

Install the Roc™ Holder onto the Analytical Column

- Thread the assembled holder onto the analytical column, making sure to use the supplied Roc™ PEEK ferrule.
- Use a ⁷/16" wrench on the Roc™ holder and a ³/8" wrench on the analytical column to tighten the holder no more than ¹/8-turn past finger-tight. Do not overtighten.

For a complete list of Roc™ LC guard columns and replacement ferrules, visit www.restek.com/Roc



An assembled Roc™ LC guard column holder.



A disassembled Roc™ LC guard column holder.



A Roc™ LC guard column holder installed on an analytical column.

*Fittings on all HPLC and UHPLC columns have 10-32 threads; however, seat depth varies. An improper seat will yield a poor connection and may affect chromatography. While all Restek® LC columns will provide a zero-dead-volume connection when used with properly installed Roc™ guard holders, analysts should consult the manufacturer when using non-Restek® columns. A detailed discussion of port configurations can be found at: http://www.restek.com/Pages/faq_lc

Questions about this or any other Restek® product? Contact us or your local Restek® representative (www.restek.com/contact-us).

Restek® patents and trademarks are the property of Restek Corporation. (See www.restek.com/Patents-Trademarks for full list.) Other trademarks in Restek® literature or on its website are the property of their respective owners. Restek® registered trademarks are registered in the U.S. and may also be registered in other countries.





