

Keep Your Lab Flowing

with RM on Your Waters ACQUITY LC Systems

Routine maintenance (RM) reduces downtime and protects your valuable analytical data. Use this guide to keep your Waters ACQUITY LC Systems operating at their best—replace these crucial components at the recommended intervals and keep extras on hand.

Analytical conditions, mobile phases and additives, sample matrices, and other factors can affect maintenance frequency.

For helpful maintenance videos and tips, plus a full list of replacement parts, visit www.restek.com

